

Name: 8BITDO GamePad  
Mode: FC30  
8Bitdo Tech HK Ltd.

Thank you to buy FC30 GamePad, It' s the best for fightingshooting, action and emulator games.














FC30 has Multi-mode, it supports PC, Smart phone, Pad, Notebook,Android iOS, Mac OSX,Windows. All popular systems and devices support.

For the happy memory of old days

8Bitdo

# Fast Startup

Power OFF: Hold down START for 3 seconds.

	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5
	Joystick	Bluetooth Keyboard	iCade	Emu-Touch Screen	USB Joystick
Power ON (Hold down key for 3 seconds)					Auto connection
Blue LED					Can be ignored
Support system					
memo	PC can use Bluetooth Adapter.	START+B+R power on. The 2nd Keyboard code.	Input method should be English.	Need ROOT Need Jailbreak	Also charge FC30 battery

## The most common situation:

1. For Android devices, use Mode 1.
2. For iOS devices, use Mode 2 or Mode 3.
3. For pure touch screen games, use Mode 4.

**Power OFF: Hold down START for 3 seconds.**



## Mode 1,2,3

Manual in detail: (Note: Make sure the GamePad battery is NOT empty!

If empty, use USB cable charge it.)

Mode 1,2,3 Bluetooth connection:

1. Turn on the power in mode 1,2,3.
2. Scan Bluetooth on Android or IOS device, and tap the “8Bitdo FC30 GamePad” to pare.
3. Map the keys in the App or Emulator you will be playing.



## Mode 4

Emu-Touch Screen mode: (Android need ROOT, IOS need Jailbreak.)

1. Download FC30 App from the official website at [www.fc30.com](http://www.fc30.com).

(iOS user can add source <http://app.fc30.com> in Cydia)


2. Turn ON power in Mode 4.

3. Run FC30 App and scan Bluetooth device, then tap the “8Bitdo FC30 GamePad” to pare.

4. If asked for pairing code, enter “0000”.

5. In Emu-touch screen mode, press hotkey SELECT+START to activate FC30 App

6. Now, just drag and drop, map the keys to the right place on screen, press **SELECT+START** to finish.




Tip: Double tap DPad or use two fingers can zoom it to fit games.

After use Mode 4, if you want to use Mode 1,2 and 3:

Note: For Android user, need to unpair the "8bitdo FC30 GamePad" first, and then reconnect it.

For IOS user, system Bluetooth will be unavailable, you must run FC30 software, and turn off Bluetooth in the software. Then, system Bluetooth will be available in 20 seconds.



1. Connect to USB port with USB cable, computer will recognize it.
2. Map the keys of the Game you will be playing.


\* Also charge FC30 battery



## Upgrade firmware from PC

# FIRMWARE UPGRADE

- 1) Turn ON: Hold down **START+L+R** for 3 seconds. Green+Blue LED will be flashing.
- 2) Connect FC30 with PC's USB port with a USB cable.
- 3) Download the FC30 upgrade software from official website and run update.exe file.
- 4) Select firmware file bluetooth\_firmware.dat and update.





## LED Light Status

1. Blue light flashing: Bluetooth disconnect.
2. Solid blue light: Bluetooth connected.
3. Green light flashing: Battery charging.
4. Green light OFF: Charging completed
5. Solid red light: Battery low.
6. All lights off: Power OFF or Sleep Mode.

Restore factory settings: Hold down START for 12 seconds.

The firmware of FC30 GamePad can be upgrade, functions will be changed or added, the final feature can be checked on the official website.