




Instruction Manual


使用说明



FlipPad 01

翻盖宝 05





- ① — L2
- ② — Status LED
- ③ — R2
- ④ — L1
- ⑤ — D-pad

- ⑥ — Star button
- ⑦ — R1
- ⑧ — X
- ⑨ — A
- ⑩ — B

- ⑪ — Home button
- ⑫ — Select button
- ⑬ — Y
- ⑭ — Start button

Android / Apple®

- * System requirement: Android 13.0 or above. OTG support is required on your device, please contact your manufacturer for more information.
- * For the latest compatibility information regarding Apple device system versions, please refer to: <https://www.8bitdo.com/apple/>

Apple®, iPadOS®, macOS®, and tvOS® are trademarks of Apple Inc., registered in the U.S. and other countries.

USB Connection

Connect the FlipPad to your Android or Apple device via the USB port and wait until it is recognized by the device.


Turbo Function

- * **D-pad, Home, Select, and Start buttons** are not supported for turbo.
- * The turbo settings will not be saved permanently and will revert to default settings after the FlipPad is powered off or disconnected.

Turbo:



Auto Turbo:



Safety Warnings


- * Please always use batteries, chargers, and accessories provided by the manufacturer.
 - * The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
 - * Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
 - * Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
 - * Any unauthorized changes or modifications to the device will void the manufacturer's warranty.
 - * This product contains small parts that may cause choking. Not suitable for children under three years old.
 - * This product features flashing lights. Individuals with epilepsy or photosensitivity should disable the lighting effects before use.
 - * Cables may cause tripping or entanglement hazards. Keep them away from walkways, children, and pets.
 - * Stop using this product immediately and seek medical attention if you experience dizziness, visual disturbances, or muscle spasms.
-


Ultimate Software

Please visit app.8bitdo.com to download and use **Ultimate Software V2 Mobile** for Android / Apple platforms.

Support

Please visit support.8bitdo.com for further information and additional support.





① — L2

② — 状态指示灯

③ — R2

④ — L1

⑤ — 方向键

⑥ — 星号键

⑦ — R1

⑧ — X

⑨ — A

⑩ — B

⑪ — Home 键

⑫ — Select 键

⑬ — Y

⑭ — Start 键

Android / Apple

* 要求 Android 设备系统版本为 Android 13.0 或更高版本, 且设备支持 OTG 功能, 详情请咨询设备制造商。

* 关于 Apple 设备系统版本的支持信息请参阅: <https://www.8bitdo.cn/apple>

有线连接


将 Flippad 手柄连接到 Android 或 Apple 设备的 USB 端口, 等待系统识别完成后即可使用。

连发功能

* 方向键、Home、Select、Start 键 不支持连发。

* 连发功能不会保存, 断开连接后恢复默认。

连发:



自动连发:



安全警示

- * 使用制造商认可的电池、充电器、配件和用品。
 - * 在用户使用未经认可的配件或用品时，制造商不能对用户的安全负责。
 - * 请勿自行拆卸、改装或修理设备。
 - * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
 - * 对设备的任意变动或改装，将导致制造商对设备不予保修。
 - * 产品包含小部件，可能造成窒息危险，不适合3岁以下儿童使用。
 - * 本产品使用时包含闪烁灯光效果，若有癫痫病史或光敏性反应者使用时请关闭灯光。
 - * 产品线缆可能造成绊倒或缠绕危险，请勿放置在行走区域，并远离儿童及宠物。
 - * 如产品使用过程中出现头晕、视力异常、肌肉抽搐等症状，请立即停止使用并就医。
-

固件更新

请访问 app.8bitdo.cn 获取适用于 Android / Apple 平台的 **精英软件 V2 移动版** 使用。

技术支持

请访问 support.8bitdo.cn 了解详细信息。



Manual



使用说明

