
## SN30 2.4g — instruction manual

- select

+ start

- power off: press and hold start for 3 seconds
- · power on: press start

# SN30 2.4g — 使用说明



- \* 关机:按住[start]键3秒。
- \* 开机:轻按 [start] 键。

# Super Nintendo Entertainment System & Super Family Computer & Analogue Super Nt

- 1 plug the receiver to your chosen device, blue LED blinks once per cycle
- 2 press start button on the controller to pair
- 3 blue LEDs on both the controller and receiver become solid when connection is successful

# Super Nintendo Entertainment System & Super Family Computer & Analogue Super Nt

- 1. 将接收器插入主机端口,接收器蓝灯闪烁。
- 2. 轻按手柄 [start] 键即可连接,连接成功后蓝灯常亮。

| battery               |                                |                     |
|-----------------------|--------------------------------|---------------------|
| status –              |                                | LED indicator —     |
| low battery mode      | $-\!\!\!\!-\!\!\!\!-\!\!\!\!-$ | red LED blinks      |
| battery charging      |                                | red LED stays solid |
| battery fully charged |                                | red LED turns off   |

- built-in 180 mAh Li-on with 18 hours of play time
  rechargeable via USB cable with 1 2 hour charging time
- Controller turns off in 1 minute with no connection and 15 minutes with connection but no use

电源状态 电量不足 充电中

电源指示灯状态 红灯闪烁 红灯熄灭

- \* 内置 180 mAh 锂电池,可持续使用约 18 小时。
- \* 充电时间约1-2小时,充电完成后指示灯熄灭。
- \* 开机后 1 分钟内无连接,或连接后 15 分钟无操作会自动关机。

### **Safety Warnings**

- · Please always use batteries, chargers, and accessories provided by the manufacturer.
- The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- · Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- · Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

### 安全警示

电源

### Δ

- \* 请使用制造商的电池、充电器、配件。
- \* 在用户使用第三方的配件时,制造商不能对用户的安全负责。
- 请勿自行拆卸、改装或修理设备。
- \* 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- \* 对设备的任意变动或改装,将导致制造商对设备不予保修。

# Retrieve a lost connection or connect to a new receiver

- 1 Turn on the controller then press and hold select button for 3 seconds. Blue LED starts to rapidly blink
- 2 Move the controller close to the receiver. Blue LED becomes solid when connection is successful

### 重新匹配

\* 若无法连接或者更换接收器,可在开启手柄后按住 [select] 键至指示灯快速闪烁,将手柄靠近 接收器重新配对,配对完成后接收器与手柄指示灯呈常亮显示。

### support



• Please visit support.8bitdo.com for further information & additional support

### 技术支持



\* 请访问 https://support.8bitdo.cn/ 了解详细信息。