


## Sega Saturn Retro Receiver-Instruction Manual



Sega Saturn

01

Windows

02




## Windows



\* Windows(1903) or above is required.


## Ultimate 3-Mode Controller

1. Turn the **Mode** switch to **BT** position.
2. Press the **Xbox** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Ultimate 2.4G Wireless Controller

1. Turn the **Mode** switch to **D** position.
2. Hold the **Profile** button for 5 seconds to switch to Bluetooth connection mode. (The controller will vibrate once)
3. Hold the **Star** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Ultimate Bluetooth Controller

1. Turn the **Mode** switch to **BT** position.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Ultimate 2C Bluetooth Controller

1. Press the **Home** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Ultimate C Bluetooth Controller

1. Press the **Home** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Pro 2 Bluetooth Controller

1. Turn the **Mode** switch to **D** position.
2. Press the **Start** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## SN30 Pro+ Bluetooth Controller

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## M30 Bluetooth Controller

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Lite

1. Turn the **Mode** switch to **X** position.
2. Press the **Home** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Micro

1. Turn the **Mode** switch to **D** position.
2. Press the **Home** button to turn on the controller.
3. Hold the **Pair** button for 1 second to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## SN30 Pro for Android

1. Press the **Xbox** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## SN30 Pro Bluetooth Controller

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Lite 2/Lite SE

1. Turn the **Mode** switch to **D** position.
2. Press the **Home** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Arcade Stick for Windows & Switch

1. Turn the **Connection** switch to **BT** position.
2. Turn the **Mode** switch to **X** position.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will rotate clockwise. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the arcade stick and receiver will remain solid to indicate a successful connection.




## NEOGE0 Wireless Controller

1. Turn the **Mode** switch to **BT** position.
2. Press the **Select** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## S30 Modkit

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **L+R** buttons for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## P30 Modkit

1. Press the **X+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## N64 Modkit

1. Turn the **Mode** switch to **D** position.
2. Press the **Start** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## DualSense/DualSense Edge Wireless Controller

1. Ensure the controller is OFF, hold the **Create+PS** buttons for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
2. Connect the receiver to the USB port of your Windows device.
3. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
4. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## DualShock 4 Wireless Controller

1. Ensure the controller is OFF, hold the **Share+PS** buttons for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
2. Connect the receiver to the USB port of your Windows device.
3. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
4. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




## Xbox One/Xbox Series/Xbox Elite Series 2/Xbox Elite Series 2-Core Wireless Controllers/Xbox Adaptive Controller

1. Press the **Xbox** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.



## Switch Pro Controller

1. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
2. Connect the receiver to the USB port of your Windows device.
3. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
4. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.



## Safety Warnings:



- \* Please always use batteries, chargers, and accessories provided by the manufacturer.
- \* The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- \* Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- \* Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- \* Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

## Firmware Update

\* Please visit [support.8bitdo.com](http://support.8bitdo.com) to access the Ultimate Software V2.

## Support

\* Please visit [support.8bitdo.com](http://support.8bitdo.com) for further information & additional support.