


Sega Saturn Retro Receiver-Instruction Manual



Sega Saturn

01

Windows

02


Windows



* Windows(1903) or above is required.


Ultimate 3-Mode Controller

1. Turn the **Mode** switch to **BT** position.
2. Press the **Xbox** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Ultimate 2.4G Wireless Controller

1. Turn the **Mode** switch to **D** position.
2. Hold the **Profile** button for 5 seconds to switch to Bluetooth connection mode. (The controller will vibrate once)
3. Hold the **Star** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Ultimate Bluetooth Controller

1. Turn the **Mode** switch to **BT** position.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Ultimate 2C Bluetooth Controller

1. Press the **Home** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Ultimate C Bluetooth Controller

1. Press the **Home** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Pro 2 Bluetooth Controller

1. Turn the **Mode** switch to **D** position.
2. Press the **Start** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




SN30 Pro+ Bluetooth Controller

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




M30 Bluetooth Controller

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Lite

1. Turn the **Mode** switch to **X** position.
2. Press the **Home** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Micro

1. Turn the **Mode** switch to **D** position.
2. Press the **Home** button to turn on the controller.
3. Hold the **Pair** button for 1 second to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




SN30 Pro for Android

1. Press the **Xbox** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




SN30 Pro Bluetooth Controller

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Lite 2/Lite SE

1. Turn the **Mode** switch to **D** position.
2. Press the **Home** button to turn on the controller.
3. Hold the **Select** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




Arcade Stick for Windows & Switch

1. Turn the **Connection** switch to **BT** position.
2. Turn the **Mode** switch to **X** position.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will rotate clockwise. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the arcade stick and receiver will remain solid to indicate a successful connection.




NEOGE0 Wireless Controller

1. Turn the **Mode** switch to **BT** position.
2. Press the **Select** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




S30 Modkit

1. Press the **B+Start** buttons to turn on the controller.
2. Hold the **L+R** buttons for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




P30 Modkit

1. Press the **X+Start** buttons to turn on the controller.
2. Hold the **Select** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




N64 Modkit

1. Turn the **Mode** switch to **D** position.
2. Press the **Start** button to turn on the controller.
3. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
4. Connect the receiver to the USB port of your Windows device.
5. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
6. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




DualSense/DualSense Edge Wireless Controller

1. Ensure the controller is OFF, hold the **Create+PS** buttons for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
2. Connect the receiver to the USB port of your Windows device.
3. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
4. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.




DualShock 4 Wireless Controller

1. Ensure the controller is OFF, hold the **Share+PS** buttons for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
2. Connect the receiver to the USB port of your Windows device.
3. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
4. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.





Xbox One/Xbox Series/Xbox Elite Series 2/Xbox Elite Series 2-Core Wireless Controllers/Xbox Adaptive Controller

1. Press the **Xbox** button to turn on the controller.
2. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will blink rapidly. (This is required for the very first time only)
3. Connect the receiver to the USB port of your Windows device.
4. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
5. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.



Switch Pro Controller

1. Hold the **Pair** button for 3 seconds to enter pairing mode, the **Status LED** will start rolling blink. (This is required for the very first time only)
2. Connect the receiver to the USB port of your Windows device.
3. Press the **Pair** button of the receiver, the **Status LED** will blink rapidly.
4. Both the **Status LEDs** of the controller and receiver will remain solid to indicate a successful connection.



Safety Warnings:

- * This product is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- * Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- * Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

Firmware Update

* Please visit support.bitdo.com to access the Ultimate Software V2.

Support

* Please visit support.bitdo.com for further information & additional support.